

Thomas Gas

42 Churinga Rd, ALDGATE S A 5154
Ph 08 8339-2388 Email: admin@thomastgas.com.au Fax 08 8370-8199

Regulator with NO changeover valve Operation

Your regulator is situated between your 2 LP gas cylinders – its main job is to regulate the pressure of the gas coming into your home.

This type of regulator has no valve to select which cylinder is being used therefore gas is being used from both cylinders at the same time.

To be able to control your gas usage & be able to order gas PRIOR to running out of gas completely we suggest one cylinder is left turned off.

When the service cylinder is empty turn it off and turn on the reserve cylinder all the way on using the tap on the top of the cylinder (follow pointing arrows on top of wheel)

Relight your appliance/s

Order another cylinder to replace the empty one therefore keeping your gas supplies continual.

Please phone us on 8339 2388 or email to lpgasorders@thomastgas.com.au to re-order any time day or night – orders may be left on our message service out of office hours.

Please Note: We must turn the gas off to your home so we can change the empty cylinder over. The delivered cylinder will be leak checked then both cylinders will be left turned off.